

CF13 Mobile Milk Mixer 110ltr

CF14 Static Milk Mixer 110ltr

CF16 Milk Trolley Only 110ltr

**Operating instructions**

- Put in half the amount of required water.
- Start the mixer
- Add the recommended amount of powder
- Add remaining water.
- When thoroughly mixed (approximately 5 minutes) switch off\*.
- Rinse out after use with warm water, half fill mixer with water and sterilising solution at recommended rate and leave running for 30 seconds. Clean remaining soiled areas using a brush, drain solution and rinse with cold water.

**Safety instructions**

1. Use 230 volt electrical power supply only
2. Ensure the unit is plugged into a RCD protected supply.
3. Do not place your hand in the mixer when it is running.
4. Unplug and secure electrical lead before moving the mixer.

**Maintenance instructions**

- Do not run dry
- Clean with hot water and dairy detergent at least once a week.
- Test the electrical circuits on an annual basis.
- Lubricate axles occasionally.
- Do not inflate tyres above 30 psi (2 bar).
- If liquid is seen coming out of the clear hose pipe underneath the machine, this is the early signs the mechanical seal may need replacing - failure to address this issue could lead to failure of the electric motor and possible electric shocks.

**IMPORTANT**

\* Over mixing can lead to fat separation.

\* Running the mixer for long periods of time may cause the motor to overheat which may invalidate any warranty.